

ITEM NO:EE-3099

USER MANUAL



KEEP THE MANUAL NEAR THE  
MACHINE ALL TIME AND MAKE  
SURE ALL USERS HAVE READ  
THIS.

FOLLOW THE INSTRUCTIONS  
CAREFULLY TO GRANT THE  
MACHINE A CORRECT  
FUNCTION AND LONG  
SERVICE LIFE.

EAE Automotive Equipment Company Limited

The manufacturer keeps the rights to improve the  
contents in this manual.

Tel:+86-21-32500750  
Fax:+86-21-32500785  
[Http://www.eae-ae.com](http://www.eae-ae.com)  
[sales@eae-ae.com](mailto:sales@eae-ae.com)



## Warning

- This manual is a necessary part of the product. Please read carefully.
- Keep the manual for later use when maintaining the machine.
- This machine can only be used for the designated purposes. Never use it for any other purpose.
- The manufacturer is not responsible for the damage incurred by improper use or use other than the intended purpose.

## Precaution

- The equipment can only be operated by qualified personnel with special training. Modification to any components or parts, or use the machine for other purpose without either obtaining the agreement from the producer, or observing the requirement of the instructions may lead to direct or indirect damage to the equipment.
  - ★ The equipment should be installed on the stable ground, not wooden pallet, otherwise not accurate.
- Keep the back panel 0.6M away from the wall for good ventilation. Enough room should be left on both sides for convenient operation.
- Do not put the equipment a place with high temperature or moisture, or near the heating system, water tap, air-humidifier or chimney.
- Avoid lots of dust, ammonia, alcohol, thinner or spraying binder.
- People who are not operating the machines should be kept away when it is used.
- Use appropriate equipment and tools, protective and safety equipment, including eyeglasses, earplugs and working boots.
- Pay special attention to the marks on the machine.
- Do not touch or approach the moving parts by hand during operating.
- Do not remove the safety device or keep it from working properly.

---

## Contents

1. General-----	1
2. Machine assembly-----	1
3. Controls and components-----	3
4. Indication and use of wheel balancer-----	5
5. Self-calibration of wheel balancer -----	13
6. Gauge and Laser calibration-----	13
7. Errors-----	16
8. Self- diagnoses-----	16
9. Setting machine-----	17
10. Inch/mm unit set-----	17
11. OPT function -----	18
12. Spare parts list and Exploded drawings-----	19

# 1. General

## 1.1. Technical data:

- Max wheel weight: 65kg
- Power: 0.2kw;0.37kw
- Power supply: 220v;230v;240v;110v;50hz;60hz
- Balancing accuracy:  $\pm 1\text{g}$
- 8 balancing modes: DYN, ALU1, ALU2, ALU3, ALU4, ALU5, ALUS, ST
- Balancing speed: 200r/min
- Cycle time: 8s
- Rim diameter: 10 " ~24 " (256mm~610mm)
- Sound pressure level during work cycle: <70db
- 

## 1.2. Features:

- Statistic and dynamic balancing, ALU-programs for alloy rims or special shaped
- Self diagnoses, easy to find the problem
- Apply to steel and aluminum alloy rim

## 1.3. Working environment:


- Temperature: 5~50°C
- Height:  $\leq 4000\text{m}$

# 2. Machine assembly

## 2.1. Unpack


Unpack the carton, check if missing any spare parts.

No.	Item	Qty
1	Width gauge	1
2	Conic No.1	1
	Conic No.2	1
	Conic No.3	1
	Conic No.4	1
3	Quick release nut	1
4	Thread hub	1
5	Bowl for quick nut	1
6	Pad for bowl	1
7	Balancing hammer	1
8	100g weight	1
9	Allen wrench	1



## 2.2. Install


- The equipment should be installed on the stable ground, not wooden pallet, otherwise not accurate.
- Keep the back panel 0.6M away from the wall for good ventilation. Enough room should be left on both sides for convenient operation.



## 2.3. Fix balancer to floor with screws on the bottom.

## 2.4. Install adaptor

The wheel balancer is supplied complete with cone type adaptor for fastening wheel with central bore. (see below picture)




## 2.5. Install wheel

Clean wheel, take off counterweights, check pressure of wheel.

Choose the way of installation according to the type of wheel.



Main shaft-wheel—  
suitable cone( small head towards inside)—quick handle nut




Main shaft-suitable cone(big head towards inside)  
—wheel—quick handle nut


**Attention: May add a wheel, and hold the wheel to help install the thread hub. When installing or taking off wheel, do not let wheel move on the shaft, to avoid scratching shaft.**

### 3. Controls and components

No.	Item	Standard/Option al
A	Switch	S
B	Head with tool tray	S
C	Gauge head	S
D	Main shaft	S
E	Pedal breaker	S
F	Safe guard	S
G	Key board	S
H	Width Gauge	O



## Display plate (G)



1. inside amount of unbalance
2. Standby displays electronic brake indication status
3. outside amount of unbalance
4. Digital readout, inside position of unbalance
5. Digital readout, outside position of unbalance
6. Indicator bar for ruler when pull out ruler for outside position
7. Indicator bar for ruler when pull out ruler for inside position
8. "ALU" correction mode selected, can choose following different modes: (finishing input "a" "d" "b", press ALU to choose following modes)

### Eight balancing modes

Icon	Balancing mode	Operation	Add weights
	Standard/Default	<ol style="list-style-type: none"> <li>1. Turn on machine</li> <li>2. Input a,b,d value</li> <li>3. Start spin, after spin stop</li> </ol>	Clip on weights on both sides of rim edge
	ALU1	<ol style="list-style-type: none"> <li>1. Turn on machine</li> <li>2. Input a,b,d value</li> <li>3. Press ALU button, indicator lit up</li> <li>4. Start spin, after spin stop</li> </ol>	Add adhesive weights on the rim shoulder both sides
	ALU2	<ol style="list-style-type: none"> <li>1. Turn on machine</li> <li>2. Input a,b,d value</li> <li>3. Press ALU button, indicator lit up</li> <li>4. Start spin, after spin stop</li> </ol>	Clip on weight on inside rim edge, add adhesive weight on outside rim shoulder

	ALU3	<ol style="list-style-type: none"> <li>1. Turn on machine</li> <li>2. Input a,b,d value</li> <li>3. Press ALU button, indicator lit up</li> <li>4. Start spin, after spin stop</li> </ol>	Add adhesive weights on the rim shoulder both sides
	ALU4	<ol style="list-style-type: none"> <li>1. Turn on machine</li> <li>2. Input a,b,d value</li> <li>3. Press ALU button, indicator lit up</li> <li>4. Start spin, after spin stop</li> </ol>	Clip on weight on inside rim edge, add adhesive weight on outside rim shoulder
	ALU5	<ol style="list-style-type: none"> <li>1. Turn on machine</li> <li>2. Input a,b,d value</li> <li>3. Press ALU button, indicator lit up</li> <li>4. Start spin, after spin stop</li> </ol>	Add adhesive weight on inside rim shoulder, clip on weight on outside rim edge
	ALUS	<ol style="list-style-type: none"> <li>1. Turn on machine</li> <li>2. Press ALU button, indicator lit up</li> <li>3. Input aI,aE,d value</li> <li>4. Start spin, after spin stop</li> </ol>	Add adhesive weights on the two positions gauge head touch
	Static mode, for motorcycle wheels	<ol style="list-style-type: none"> <li>1. Turn on machine</li> <li>2. Input a,b,d value</li> <li>3. Press ALU button</li> <li>4. Start spin, after spin stop</li> </ol>	Add adhesive weight

#### Key board (H)

Icon	Function	Icon	Function
	Rim data		Data add key
	Data reduction key		Unbalance display pitch and threshold
	Selection of "ALU" modes		Stop/Cancel/
	Start		Automatic brake switch
			Optimization of unbalance


## 4. Indication and use of wheel balancer

### 4.1. DYN (Standard/Default) mode

4.1.1. Clean wheel, take off counterweights, check pressure of wheel. Choose the way of installation according to the type of wheel.



Main shaft-wheel—



Main shaft-suitable cone(big head towards inside) —wheel—quick handle nut

suitable cone( small head towards inside)—quick handle nut

—wheel—quick handle nut

**Attention: May add a wheel, and hold the wheel to help install the thread hub. When installing or taking off wheel, do not let wheel move on the shaft, to avoid scratching shaft.**

4.1.2. Turn on machine

4.1.3. Input a b d value

Turn on machine, choose right way to install wheel according to the type of wheel. Set “a” “b” “d” values:

- set “a” value: move the gauge to measuring position as illustrated as Fig.1, hold the gauge still in position for approx. 4 seconds, successful memorization is given, then return the gauge to position

0.(The value measured in automatic mode appear on the display). Or press and and to set manually.

- set “b” value: set nominal diameter “b” marked on the wheel or use the width gauge to measure the value of ”b” as **Fig.2a**, then press and to set manually. If the balancer is with optional automatic width ruler, let the gauge head touch the rim as **Fig.2b**, until there is a sound, means successful memorization is give, then release the gauge.

- set “d” value: this value measured in automatic mode same time as “a” value setting, or press and to set manually.




Fig.1




Fig.2 a



Fig.2 b

4.1.4. Put down the guard and press to perform a measuring spin.

4.1.5. In a few seconds the wheel is brought to operating speed and begin measuring unbalance, the unbalance values

---

remain on instruments 1 and 3 when the wheel stopped. Press  may check the real unbalance value under threshold.

4.1.6. Anticlockwise moving wheel slowly, until the right LED lit up full, clip weight on 12 o'clock position (Fig.3)





Fig. 3

4.1.7. Anticlockwise moving wheel slowly, until the left LED lit up full, clip weight on 12 o'clock position (Fig.4)




Fig. 4

4.1.8. After finishing clipping the counterweights, put down the guard or press  , to perform balancing spin again, if comes out 00 00, means balancing succeed. (Fig.5)



Fig. 5

## 4.2. ALU-1 mode (ALU-1, ALU2 same operation, only the position to add weights different)

4.2.1. Set "a" "d" "b" values

4.2.2. Press  until ALU1 indicator lit up

4.2.3. Put down the guard and press  to perform a measuring spin.

4.2.4. In a few seconds the wheel is brought to operating speed and begin measuring unbalance, the unbalance values

remain on instruments 1 and 3 when the wheel stopped. Press  may check the real unbalance value under threshold.

4.2.5. Anticlockwise moving wheel slowly, the displays with right LED's lit up full indicate the correct angular position where to mount the counterweights, 12 o'clock position outside, as Fig.6, add the counterweight.





Fig. 6

4.2.6. Anticlockwise moving wheel slowly, the displays with left LED's lit up full indicate the correct angular position where to mount the counterweights, 12 o'clock position inside, as Fig.7, add the counterweight.




Fig. 7

4.2.7. After finishing mounting the counterweights, put down the guard and press  to perform balancing spin again, if comes out 00 00, means balancing succeed. (Fig.8)



Fig. 8

#### 4.3. ALU-S mode

**This mode is used for special rim, if ALU1/ALU2 can not be used, you should choose ALUS mode.**

Input aI, aE, d value

- Set “aI”: pull gauge out let the gauge head touch the position of FI for 4 seconds, may press  and  and  to change
- Set “aE”: pull gauge out let the gauge head touch the position of FE for 4 seconds, may press  and  and  to change

- Set “dI”: read from rim, may press  and  to change
- Set “dE”: read from rim, may press  and  to change




Fig. 9

Put down the guard and press  to perform a measuring spin.

4.3.1. 9o'clock position to add weight

Set SLC as OFF according to 9.1

#### **Laser indication operation (setting option SLC for OFF) selection**

Anticlockwise moving wheel slowly, until the right LED lit up full, add weight on 9o'clock position (Fig.10)




Fig. 10

Anticlockwise moving wheel slowly, until the left LED lit up full, add weight on 9 o'clock position (Fig.11)





Fig. 11

After finishing mounting the counterweights, put down the guard and press  to perform balancing spin again, if comes out 00 00, means balancing succeed. (Fig.12)



Fig. 12

#### 4.3.2. Use a ruler to increase weight

Set SLC as ON according to 9.1  
drawing rule operation (setting option SLC for ON) standard




Fig. 13

Anticlockwise moving wheel slowly, until the right LED lit up full (Fig.14)





Fig. 14



Take off proper counterweight to be hold by the gauge head as Fig. 16




Fig. 15




Fig. 16

Pull out gauge until there is a square comes in the middle window (Fig. 17)





Fig. 17

Release the counterweight and let it stick on rim (Fig. 18)



Fig. 18



Anticlockwise moving wheel slowly, until the left LED lit up full (Fig.19)




Fig.19

Take off proper counterweight to be hold by the gauge head as Fig. 16

Pull out gauge until there is a square comes in the middle window (Fig. 20)




Fig. 20

Release the counterweight and let it stick on rim (Fig. 21)




Fig. 21

Then turn down safe guard and press  to start spin, comes Fig. 22 means the wheel is balanced.



Fig. 22

#### 4.3.3 ALUS split function

**Note: Only ALU-S mode can use this function. And Operator must be experienced.**

1	In the case of the ALU-S mode, press 	comes >			
2	Through the  and  input number of spokes, then press 	comes >			
3	Keep the next spoke( either direction is ok) on the position of 12 o'clock, press 	comes >			
4	Anticlockwise rotate wheel by hand slowly, until the outside SP1 LED lit up full, add the adhesive weight (to stick the weights on position of 12 o'clock or else depends SLC=On or Off)	comes >			
5	Anticlockwise rotate wheel by hand slowly, until the outside SP2 LED lit up full, add the adhesive weight (to stick the weights on position of 12 o'clock or else depends SLC=On or Off)	comes >			
6	Put down safe guard and press 				
Successful operation					

## 5. Self-calibration of wheel balancer

### 5.1. Self-calibration of wheel balancer

5.2. Turn on balancer, install a medium size wheel (14"-16) which can use clip-on weight, set "a b d" value, then

**Do the self-calibration whenever you think the balancer is not accurate. The 100g weight must be accurate.**

Step 1	Press  and hold, then press 	comes	  
Step 2	Put down safe guard or press  start spin, after spin stop	comes	  
Step 3	Open the safe guard and clip a 100 gram weight on the outside 12 o'clock position, put down safe guard and press  to start spin, after spin stop	comes	  
Step 4	Open the safe guard and clip a 100 gram weight on the inside 12 o'clock position, put down safe guard and press  to start spin, after spin stop	comes	  
self-calibration finished			


## 6. Gauge and Laser calibration

Press  +  to enter Gauge and Laser calibration, press  and  to choose, press  to confirm

No.	Display	Meaning
1	  	Calibration of distance gauge 6.1
2	  	Calibration of diameter gauge 6.2
3	  	Calibration of width gauge 6.3
4	  	Calibration of laser 6.4

### 6.1 Calibration of distance gauge

press  and  to show

   then press 	comes >	  
--	---------	---

to confirm		
pull gauge to position “0” and hold, press 	comes >	<b>CAL.</b>  <b>P. 15</b>
pull gauge to position “15” and hold, press 	comes >	<b>CAL.</b>  <b>End</b>
Calibration of distance gauge finished		

## 6.2 Calibration of diameter gauge 6.2



press  and  to show <b>CAL.</b>  <b>d 18</b> then press  to confirm	comes >	<b>CAL.</b>  <b>14.0</b>
Set “d” by press  and  , ( for example if it is 16 inch, make it 16)	comes >	<b>CAL.</b>  <b>16.0</b>
move gauge to touch the edge of rim and keep still		
press 	comes >	<b>CAL.</b>  <b>End</b>

Calibration of diameter gauge finished

## 6.3 Calibration of width gauge (if provided)


No tyres need to be installed

1	press  and  to show <b>CAL.</b>  <b>LAr</b> then press  to confirm	comes >	<b>CAL.</b>  <b>F0</b>
---	---	---------	---

2	keep width gauge as position	>	
3	press 	comes >	<b>CAL.</b>  
4	keep width gauge as position	>	
5	Press 	comes >	<b>CAL.</b>  <b>End</b> calibration finished
Calibration of width gauge finished			

#### 6.4 Calibration of laser (if provided)

press  and  to show <b>CAL.</b>  <b>LAG</b> then press  to confirm	comes >	<b>CAL.</b>  
Automatic confirmation	comes >	<b>CAL.</b>  

	>	
Press 	comes >	<b>CAL.</b>  <b>End</b> 
Calibration of laser finished		

## 7. Errors

Various abnormal conditions can arise during machined operation by the microprocessor, if comes the errors, must stop operation, find the reason and the solution according, if the error persists, consult the supplier.

No.	Errors	Reasons	Solution
1	<b>Err.</b>  <b>- 1 -</b>	1. No spin 2. Shaft spin	1 . If no spin, check or change power board 2. If spin, check or change position pick up board and computer board 3. Adjust position pick up board support
2	<b>Err.</b>  <b>- 2 -</b>	1. No wheel or wheel not locked tightly 2. Position pick up board problem	1. Lock tightly 2. check or change position pick up board
3	<b>Err.</b>  <b>- 3 -</b>	1. No enough pressure in wheel 2. Wheel distortion	1. Add proper pressure in wheel 2. Check wheel
4	<b>Err.</b>  <b>- 4 -</b>	1.Position pick up board problem 2. Computer board problem	1.Check or change position pick up board 2.Check or change computer board
5	<b>Err.</b>  <b>- 5 -</b>	1. Micro switch problem 2. Computer board problem	1.Check or change Micro switch 2.Check or change computer board

6		1. Power board problem 2. Computer board problem	1. Check or change power board 2. Check or change computer board
7		1. Program lost 2. Computer board problem	1. Self calibration 2. Check or change computer board
8		1. No add 100g weight during self calibration 2. Computer board problem 3. Power board problem	1. Add 100g weight 2. Check or change computer board 3. Check or change power board
9		1. Micro switch problem 2. Computer board problem	1. Check or change micro switch 2. Check or change computer board
10		1. Computer board problem 2. Power board problem	1. Check or change computer board 2. Check or change Power board

## 8. Self- diagnoses

Press  and hold, then press  goes to self diagnoses, press  to next, press  to escape

Order	Display	Function	Function normal
1		Display	All lit up
2		Position pick up board	POS changes in 0-127
3		Distance potentiometer	Left window data is 327-340, when pull gauge out, the data changes
4		Diameter potentiometer	left window data is 327-340, turn ruler to another direction, data changes
5		Width potentiometer	left window data is 327-340, turn ruler to another direction, data changes
6		Pressure sensor	Use hand to press main shaft, 4X-4X 6X-6X changes

## 9. Setting machine

### 9.1. Machine setting

Press  and hold, then press  goes to set machine, press  and  to change, press  to next

Order	Display	function	choice
1	<b>F In</b> <input type="text"/> <input type="text"/> <b>S</b>	Unbalance display threshold	5/10/15
2	<b>SP.</b> <input type="text"/> <input type="text"/> <b>On</b>	Sound	On/off
3	<b>SLC</b> <input type="text"/> <input type="text"/> <b>OFF</b>	When ALU-S mode if use gauge head to add weight	OFF to 9 point laser, no laser has to choose ON to paste ON the ruler
4	<b>Erg</b> <input type="text"/> <input type="text"/> <b>On</b>	Tire weight	On/off
5	<b>ASL</b> <input type="text"/> <input type="text"/> <b>On</b>	Safe guard	ON: Put down safe guard to start spin OFF: Put down safe guard then press start to start spin
6	<b>Unit</b> <input type="text"/> <input type="text"/> <b>Gr</b>	Unit of weight	Gram/ Ounce

## 10. mm / inch unit set

★Press   to set safe guard







Display	Function	Explain
<b>Inh</b> <input type="text"/> <input type="text"/> <b>On</b>	inch	Diameter and width are displayed in inches
<b>Inh</b> <input type="text"/> <input type="text"/> <b>OFF</b>	mm	Mm diameter and width

## 11. OPT function

**Note: When unbalance value is too much, choose OPT, and operator must be experienced.**


Install wheel, input a b d value

1	Press 	comes>	<b>OPT</b> <input type="text"/> <input type="text"/>
2	Put down safe guard and press 	comes>	<b>C-3</b> <input type="text"/> <b>180</b>


3	With the help of tire changer, change the rim and rubber 180 degree	reference >		
4	Then put down safe guard and press 	comes >		
5	Rotate wheel until four indicators lit up (two on both sides, the dark spot in the right side picture), mark the position C with chalk on rubber	reference >		
6	Rotate wheel until two indicators lit up (one on both sides, the dark spot in the right side picture), mark the position D with chalk on rim	reference >		
7	With the help of tire changer, change the rim and rubber to make C and D match	reference >		
8	Put down safe guard and press 	comes >		If unbalance is less than before, OPT succeed

## 12. Spare parts list and Exploded drawings


ITEM NO	DESCRIPTION	PART NO.	Q'TY
1	Body	2064814	1
2	Foot lever	2064939	1
3	Brake pedal	2064962	1
4	Brake ring	2064941	2
5	Brake lever	2064944	1
6	Brake pads	3005142	1
7	Hex nut GB41 /M4	6000341	1
8	Hex nut GB41 /M8	6000127	2
9	Hex nut GB41 /M6	6000309	11
10	Connecting	2064942	2
11	Connecting rod	2065534	1
12	Bolt GB2673 M6X12	6000417	2
13	Hex nut GB889 /M8	6000148	2
14	Bolt GB70 /M6X25	6000294	6
15	Hex nut GB41 /M6	6000233	2
16	Tension spring	2010701	1
17	Bolt GB70 M10X60	6000289	1
18	Flat washer GB95/Φ10	6000134	1
19	Flat washer GB95 /Φ38x10x3	2037401	2
20	Hex nut GB889 M10	6000143	1
21	Bolt GB80 M6X12	6000230	2
22	Bolt GB70/M6X35	6000207	1
23	Motor MY6324	4003001	1
24	Belt 380x5	6000171	1
25	Fixed seat	2034501	1
26	Flat washerΦ6	6000138	4
27	Bolt GB70/M6X30	6000120	2
28	Holder	2034301	3
29	Power Switch	4000801	1
30	Plug	4001901	1
31	Cable glands	4002201	1
32	Power box	2065781	1
33	Bolt GB818 M5X16	6000271	4
34	Small side plate	2043601	1
35	Hex nut GB41 /M6	6000125	4




ITEM NO	DESCRIPTION	PART NO	Q'TY
1	Body	2065447	1
2	Small side plate	2043601	1
3	Plug	4001901	1
4	Cable glands	4000901	1
5	Power Switch	4000801	1
6	Holder	2034301	3
7	Motor MY6324	4003001	1
8	Belt 3805	6000171	1
9	Fixed seat	2034501	1
10	Flat washer $\Phi 6$	6000138	4
11	Hex nut GB41 /M6	6000309	7
12	Bolt GB70/M6X30	6000120	2
13	Power box	2065781	1
14	Bolt GB818 M5X16	6000271	4
15	Hex nut GB41 /M6	6000125	4
16	Bolt GB70/M6X25	6000294	3
17	Bolt GB818 M5X10	6000270	2




ITEM NO	DESCRIPTION	PART NO.	Q'TY
1	Screw M10X160	6000201	1
2	Flat washer GB95/Φ10	6000134	6
3	Horizontal screw M10X160	6000176	1
4	Pressure sensor	4001701	2
5	Spring washer GB93/Φ10	6000197	3
6	Spring washer GB93Φ30x10x3	2052501	1
7	Spring washer GB93Φ38x10x3	2037401	1
8	Screw GB5783 M10X25	6000184	2
9	Complete axle	2032901	1
10	Bolt GB818/M4X10	6000267	4
11	Thread hub	2042201	1
12	Bolt GB70/M10X160	6000259	1
13	Tower spring	2042801	1
14	Plastic lid	3005013	1
15	Conic N0.1	2033401	1
16	Conic N0.2	2033501	1
17	Conic N0.3	2033601	1
18	Conic N0.4	2033701	1
19	Hex nut GB41 M10	6000336	5
20	Copper backing	6000159	4
21	Allen wrench	6000169	1
22	Retaining ring	2067389	1
23	Support	2034001	1
24	Position pick-up board	5000401	1




ITEM NO	DESCRIPTION	PART NO.	Q'TY
1	Power box	2064782	1
2	Electric power board	5001321	1
3	Support	4004380	4
4	Conducting strip	3005175	1
5	Resistor	5001350	1
6	Capacitor	5001351	1
7	Hex nut GB41 M5	6000125	2
8	Hex nut GB41 M8	6000127	1
9	Bolt GB818 M5X16	6000271	2
10	Washer GB862/Φ8	6000142	1




ITEM NO	DESCRIPTION	PART NO	Q'TY
1	Shaft	2064812	1
2	Plastic sleeve	2064398	1
3	Distance sensor board	2067562	1
4	Alumi num ruler	2046301	1
5	Footage number	5001388	1
6	Distance pick-up board	2067563	1
7	Distance pick-up board	2067439	1
8	Potentiometer RV24/202	4004471	1
9	Ruler head	2067417	1
10	Return support	2064799	1
11	Distance sensor board	2067437	1
12	Bolt M3X10	6000375	1
13	Hex nut GB41 M3	6000124	1
14	Bolt GB845 ST4.2X16	6000160	2
15	Bolt GB80 M6X12	6000230	2
16	Bolt GB70 M6X20	6000114	1
17	Bolt GB818M5*16	6000271	2
18	Tension spring	2034401	1




ITEM NO	DESCRIPTION	PART NO.	Q'TY
1	Head with Tools Tray	3005394	1
11	Bolt GB818/ M5X16	6000271	3
3	Fix Plate	2066356	1
4	LCD Computer bard	5001370	1
5	Computer bard	5001436	1
6	Bolt GB819/M3X16	6000374	14
8	Spacer support	4004389	4
9	Hex nut GB41 M3	6000124	18
2	Key board	5001439	1



ITEM NO	DESCRIPTION	PART NO.	Q'TY
1	Protection box	2043701	1
2	Plastic ferrule	3002301	2
3	Shaft	2036601	1
4	Ferrule	2034201	1
5	Tension spring	2053501	1
6	Bolt GB70/M6X10	6000130	1
7	Bolt GB70/M6X20	6000102	2
8	Washer GB95/Φ8	6000142	2
9	Hex nut GB41 M8	6000127	2
10	Screw GB5783 M10X25	6000184	3
11	Washer GB95/Φ10	6000134	3
12	Spring washer GB93/Φ10	6000197	3
13	Hex nut GB41 M10	6000123	3
14	Bolt GB5783 M6X35	6000207	1
15	Bolt GB70 M8X45	6000435	1
16	Micro switch	4004436	1
17	Bolt GB818 M4X30	6000430	2
18	Hex nut GB41 M4	6000341	2
19	Bend pipe	2033301	1
20	Hex nut M8	6000127	1
21	Plastic cover (0716)	3002501	2
22	Bolt GB70 M6X45	6000435	2
23	Bolt GB70 M6X20	6000114	4
24	Hex nut M6	6000309	6



ITEM NO	DESCRIPTION	Q'TY
1	Fix plate	1
2	Support arm	1
3	Turning holder	1
4	Stop collar	1
5	Potentiometer	1
6	Turning arm	1
7	Ruler rod	1
8	Measuring head	1
9	Bolt GB70 M6X15	3
10	Bolt GB70 M6X20	4
11	Flat washer GB95 $\Phi$ 10	3
12	Bolt GB70 M10X25	3
13	Hex nut GB41 M10	3
14	Bolt GB80 M6X8	1
15	Bolt GB818 M5X16	2
16	Bolt GB80 M4X6	5
17	Bolt GB818 M4X16	2
18	Hexagon nut GB41 M6	1
19	Turning tension spring	1
20	Turning torsional spring	1
21	A16A lower cover	1
22	A16B upper cover	1
23	Bolt GB845 ST2.9X10	6



ITEM NO	DESCRIPTION	PART NO.	Q' TY
1	Package box	7000114	1
2	Conic 4	2033701	1
3	Conic 3	2033601	1
4	Conic 2	2033501	1
5	Conic 1	2033401	1
6	Locking nut	2042901	1
7	Thread rod	2042201	1
8	Plastic bowl	3005018	1
9	Rubber buffer	3005019	1
10	Hammer	4003601	1
11	Counterweight	6000210	1
12	Spanner	6000169	1

